



PLACE DOCK FRAME ON FLOAT, THEN HOOK BRACKET OVER LOWER FRAME TUBE AND PUT BOLT THROUGH BRACKET INTO SLOT IN FLOAT AND ATTACH USING WASHER AND NUT. DO THIS ON ALL FOUR CORNERS OF EVERY FLOAT.