

DOCK RITE, INC.

18250 203rd Street ~ Hutchinson, MN. 55350 ~ USA
Phone 320-587-0644 ~ Fax 320-587-3109
1-888-407-3292

VINYL DECKING INSTRUCTIONS

1. After dock frame assembly and installation- place vinyl panels on dock frame starting from shore (use panels with cut outs for around posts).
2. After all panels are in place, align and check to make sure panels interlock to each other.
3. Using self drilling screws that are provided. Fasten first panel down using holes in center of vinyl by screwing the decking down to the alum frame using a cordless drill.
4. **Make sure to fasten at least the panels on the ends of each section using 4 screws.**
5. Dock Rite has provided enough screws to fasten all the panels down. **(recommended)**
6. It is up to customer but they may leave panels screwed on during removal and installation if weight isn't a concern.

